



Mounting instructions for Klepper Spray deck

Please follow the directions below to mount your new KLEPPER spray deck on the coaming.

Applying the velcro tape:

The enclosed velcro tape must be applied to the lower outside edge of your wooden coaming. The self - adhesive on the tape works best above 65°F and the coaming must be dry, free of oil, steam or grease. You may consider cleaning the coaming with denatured alcohol and a soft cloth to apply the tape.

Pull off the tape's protective seal and press the tape against the wood coaming parallel to the lower outer edge of the coaming. Starting from the mast bracket, apply the tape from the mast bracket towards the stern. Position the tape by sections to get a nice parallel fit with the coaming. If you have a two-seater, please cut the tape at the metal hinge of the coaming and continue immediately after the metal hinge again. Apply **no tape to the metal hinge**.

After you have positioned the tape on the coaming, apply pressure with your fingers or hands to the tape to strengthen its adhesion to the coaming. After several years of boating, the applied tape may have to be replaced by pulling the old tape off and mounting a replacement tape.

Mounting the Spray deck:

Mount your spray deck onto the coaming by starting at the mast bracket and pressing the edge of the deck against the outer coaming, working your way carefully towards the stern as you did in applying the velcro tape.

Contains:

?	?	?	?
Alu-Lite	AE 2000/I/Tramp	AE II/Quattro XT	AE XXL

Klepper Faltschiffwerft AG, Klepperstr. 18M, D-83026 Rosenheim